



centro studi poltronova

ULTRAFRAGOLA MIRROR / NEON SYSTEM

Data sheet

The lighting system can only be inspected/repaired/replaced by an electrician following the appropriate indications provided by Centro Studi Poltronova. The system is in fact composed of two L-shaped neon tubes and 2 electronic transformers. In case of damage or if the lamps should discharge all the components can be replaced but always using the material supplied by Poltronova. However, the system has a life span > 15,000 hours, assuring long-term use for many years.

Important

Ultrafragola mirror cannot be connected to a DIMMER (light dimming control) and to any devices that regulate the light intensity.

Ultrafragola mirror can only be connected to normal switch with an ON/OFF function.

Any change/repair/replacement of the system, of any of its parts, not authorized by Centro Studi Poltronova, interrupts the product warranty.

After using it for a long time (more than 45 minutes), please wait a few minutes before lighting the lamp again. For security reasons, the fixture may not turn on completely until the components have cooled properly.

First use

At first use, the Neon lamps may not have a totally homogeneous light, however the lamps are all tested by Poltronova and it will be enough to leave them on for about 2 hours to obtain the perfect light.

Light detail

On the upper left and lower right, a very slight difference in light may be visible, since those are the points where the two neon lamps are connected. The design of the object respects the original 1970 project and for this reason some typical details of craftsmanship are visible and contribute to the value and authenticity of the object.

A possible light flicker may occur in this type of lamp. Just leave it on for a few hours so that the gas can reach an even pressure and assure a uniform light.

Here below all the useful details about the system:

Power of device: max 150 W

Neon lifespan: more than 15,000 h

Color: Ultrafragola Pink

**Centro Studi
Poltronova
per il Design srl**

via Lorenzo Bartolini 2,
I-50124 Firenze
p.iva e c.f.: 05546650481
società a responsabilità limitata

codice destinatario: X2PH38J
pec: centrostudipoltronova@gigapec.it
info: info@poltronova.it
telefono: +39 388 4261334 / 342 8223135